

### FIG.7 a

	MIXED MODE FLAG	
MIXED RECORDING MODE	"1"	
SINGLE RECORDING MODE	"0"	

### FIG.7 b

	CHANGE NUMBER -APPLICATION MODE	
MULTIPLEXED AUDIO DATA	1+1 CHANNEL DATA (011)	
MULTI—CHANNEL AUDIO DATA	2/0 CHANNEL DATA (000)	
MONAURAL AUDIO DATA	1/0 CHANNEL DATA (001)	

### FIG.7 c

#### CHANNEL NUMBER

	APPLICATION MODE	MIXED MODE FLAG
MIXEDMULTIPLEXED AUDIO DATA AND MULTI-CHANNEL AUDIO DATA	1+1	FLG="1"
	2/0	FLG="1"
MULTIPLEXED AUDIO DATA	1+1	FLG="0"
MULTI-CHANNEL AUDIO DATA	2/0	FLG="0"
MONAURAL AUDIO DATA	1/0	FLG="0"



# FIG.7 a

	MIXED MODE FLAG	
MIXED RECORDING MODE	"1"	
SINGLE RECORDING MODE	"0"	

### FIG.7 b

	CHANNEL NUMBER	
MULTIPLEXED AUDIO DATA	1+1 CHANNEL DATA (011)	
MULTI-CHANNEL AUDIO DATA	2/0 CHANNEL DATA (000)	
MONAURAL AUDIO DATA	1/0 CHANNEL DATA (001)	

## FIG.7 c

	CHANNEL NUMBER	MIXED MODE FLAG
MIXED MULTIPLEXED AUDIO DATA	1+1	FLG="1"
AND MULTI—CHANNEL AUDIO DATA	2/0	FLG="1"
MULTIPLEXED AUDIO DATA	1+1	FLG="0"
MULTI-CHANNEL AUDIO DATA	2/0	FLG="0"
MONAURAL AUDIO DATA	1/0	FLG="0"